



DEPARTURE ROUTE DESCRIPTION

TAKE-OFF RWY 12:

CANCUN ONE ALPHA: Climb on R-120 to 8 DME. Make right teardrop turn within 11 NM towards CUN VOR/DME. Depart CUN according to MCA via assigned route or according to ATC instructions. Minimum MCA to leave NAVAID on all airways is 2000.

CUPTTE ONE, KUMOK ONE, SAMED ONE ALPHA: Climb on R-120 to 8 DME. Turn left and proceed on the 11 DME Arc until intercepting the corresponding CUN radial to the respective fixes SAMED, KUMOK, or CUPTTE. Continue on assigned route and maintain 7000 or according to ATC instructions.

PAMUL ONE ALPHA: Climb on R-120 to 8 DME, turn right and proceed on 11 DME Arc until intercepting CUN R-184 to PAMUL. Continue on assigned route and maintain 7000 or according to ATC instructions.